

HOT AT ALL TIMES
POWER DISTRIBUTION CENTER (LEFT SIDE OF ENGINE COMPT)
HOT IN RUN OR START
JUNCTION BLOCK (LEFT SIDE OF DASH)
HOT AT ALL TIMES
IGNITION SWITCH
ACC
LOCK
OFF
START
RUN
INTAKE AIR TEMPERATURE SENSOR (TOP FRONT OF ENGINE)
(LEFT SIDE OF ENGINE COMPT)
STARTING CHARGING SYSTEM
COMPUTER DATA LINES SYSTEM
(REAR OF ENGINE)
STARTING CHARGING SYSTEM
(RIGHT REAR OF ENGINE)
(RIGHT REAR OF ENGINE COMPT)
POWERTRAIN CONTROL MODULE (RIGHT REAR OF ENGINE COMPT)
KNOCK SENSOR 2 (FRONT OF ENGINE)
KNOCK SENSOR 1 (LEFT SIDE OF ENGINE)
CRANKSHAFT POSITION SENSOR (FRONT OF ENGINE)
CAMSHAFT POSITION SENSOR (RIGHT FRONT OF ENGINE)