


BUSHINGS, BEARING & THRUST WASHER LOCATOR



Item	Part Number	Description
1	7D014	Front pump support washer No. 1T
2	7C096	Sun gear thrust bearing and race assembly No. 2B and 3B
3	7E486	Part of the overdrive carrier (7E031)
4	7F240	Direct clutch bearing and race assembly No. 4B
5	7G178	Sun gear thrust bearing and race assembly No 5B
6	7L326	Center support thrust washer
7	7F374	Intermediate clutch thrust bearing No. 8B
8	7C096	Intermediate brake thrust washer
9	7D234	Sun gear thrust bearing and race assembly No 10B, 12B, 15B

Item	Part Number	Description
10	7D090	Forward clutch hub thrust washer No. 9T
11	7H334	Forward carrier bearing and race assembly No 11B
12	7D234	Sun gear thrust bearing and race assembly No 10B, 12B, 15B
13	7L339	Forward carrier lube dam
14	7A166	Planetary carrier thrust washer
15	7D234	Sun gear thrust bearing and race assembly No 10B, 12B, 15B
16	7G178	Bearing and race assembly No. 16B
17	7B368	Park gear thrust washer (fixed yoke)
18	7B368	Park gear thrust bearing (slip yoke)

081987712

Fig. 39: Bushings, Bearing & Thrust Washer Locator
 Courtesy of FORD MOTOR CO.