


# MAIN COMPONENTS & FUNCTIONS



Item	Part Number	Description
1	7902	Torque converter
2	7A103	Pump assembly
3	—	Overdrive clutch assembly
4	—	Coast clutch assembly
5	7M101	Turbine shaft speed (TSS) intermediate shaft speed sensor
6	7B446	Overdrive planet assembly
7	—	Intermediate clutch assembly
8	—	Direct clutch assembly
9	—	Forward clutch assembly
10	7A398	Forward planet assembly
11	—	Reverse clutch assembly
12	7D006	Reverse planet assembly
13	7H103	Output shaft speed sensor (OSS)
14	7060	Output shaft assembly
15	7A089	Low/reverse mechanical diode (OWC)

Item	Part Number	Description
16	7A658	Center shaft assembly
17	7A089	Coast mechanical diode (OWC)
18	7017	Input shaft

00197714

**Fig. 41: Sectional View Of Automatic Transmission**  
 Courtesy of FORD MOTOR CO.