

IDENTIFICATION

The M50D identification tag is located on left side of transmission main case. Certification label, located on left side door lock pillar, also lists applicable transmission identification codes.