

TRANSMISSION SERVICING - M/T

MANUAL TRANSMISSION SERVICING Ford Motor Co. - MTX-75 5-Speed

IDENTIFICATION

TRANSMISSION IDENTIFICATION

Application	Transmission
Contour/Mystique	MTX-75 5-Speed

LUBRICATION

SERVICE INTERVALS

Check fluid level at 15-month or 15,000-mile intervals. Draining and refilling are not required except at time of overhaul or service.

CHECKING FLUID LEVEL

Ensure vehicle is level. Check lubricant level at filler plug hole on side of transmission. Lubricant should be within 1/4" of filler hole bottom. Add lubricant as necessary to correct fluid level.

RECOMMENDED FLUID

On complete refill, add 2 percent (1.75 ounces) of Ford Friction Modifier (F3TZ-19B546-MA) or equivalent meeting Ford specification WSP-M2C196-A.

FLUID CAPACITY

TRANSMISSION REFILL CAPACITIES

Application	Pts. (L)
Contour & Mystique ⁽¹⁾	5.5 (2.6)
(1) Includes 1.75 ounces of friction modifier.	

ADJUSTMENTS

SHIFT LINKAGE

NOTE: No in-service adjustments are necessary.

TORQUE SPECIFICATIONS

TORQUE SPECIFICATIONS

Application	Ft. Lbs. (N.m)
Drain & Fill Plug	29-43 (40-58)