

# ENGINE IDENTIFICATION

**NOTE:** For repair procedures not covered in this article, see **ENGINE OVERHAUL PROCEDURES** article in **GENERAL INFORMATION**.

The Vehicle Identification Number (VIN) is located on the upper left side of the dash and is visible through the windshield. The eighth character identifies engine size. See **ENGINE IDENTIFICATION CODE** table.

## ENGINE IDENTIFICATION CODE

Engine	Code
4.0L SFI	S

Some engines are manufactured with oversize or undersize components. These engines are identified by a letter code stamped on a boss between ignition coil and distributor. Letters are decoded as follows:

- "B" indicates all cylinder bores are .010" (.25 mm) oversize.
- "C" indicates all camshaft bearing bores are .010" (.25 mm).
- "M" indicates all main bearing journals are .010" (.25 mm).
- "P" indicates one or more connecting rod journals are .010" (.25 mm) undersize.
- "PM" indicates all main journals and one or more rod journals are .010" (.25 mm) undersize.