

HOT IN RUN
JUNCTION BLOCK
HOT AT ALL TIMES
POWER DISTRIBUTION CENTER
HOT IN RUN OR START
JUNCTION BLOCK
SHIFT LOCK SOLENOID
HVAC UNIT
BLOWER MOTOR RELAY
BLOWER MOTOR
INTERIOR LIGHTS SYSTEM
A/C HEATER CONTROL
ILLUM LAMPS
HOT AT ALL TIMES
POWER DISTRIBUTION CENTER
COOLING FAN RELAY
A/C COMPRESSOR CLUTCH RELAY
RADIATOR COOLING FAN
A/C COMPRESSOR CLUTCH
A/C LOW PRESSURE SWITCH (ON ACCUMULATOR)
A/C HIGH PRESSURE SWITCH (ON DISCHARGE LINE BETWEEN COMPRESSOR AND CONDENSOR INLET)
A/C SIGNAL SELECT
A/C SWITCH SENSE SIGNAL
RAD FAN RLY
A/C COMP RLY
POWERTRAIN CONTROL MODULE (LEFT FENDER SIDE SHIELD)