

POWER DISTRIBUTION CENTER (RIGHT FENDER SIDE SHIELD)
COOLING FAN RELAY
A/C COMPRESSOR CLUTCH RELAY
POWER STEERING PRESSURE SWITCH (BEHIND POWER STEERING PUMP)
DUTY CYCLE EVAPORATE SOLENOID (RIGHT SIDE OF SAFETY WALL)
(RIGHT REAR OF ENGINE)
A/C COMPRESSOR CONTROL RELAY
CRUISE CONTROL SYSTEM
A/C LOW PRESSURE SWITCH
A/C HEATER CONTROL SWITCH
STOP LAMP SWITCH
(ENGINE HARNESS, LEFT REAR OF ENGINE COMPT)
(ENGINE HARNESS, LEFT REAR OF ENGINE COMPT)
CRUISE CONTROL SYSTEM
POWERTRAIN CONTROL MODULE (LEFT SIDE FENDER SHIELD)
THROTTLE POSITION SENSOR (ON THROTTLE BODY)
BATTERY TEMPERATURE SENSOR (BOTTOM OF BATTERY TRAY)
DIAGNOSTIC SPLICE BLOCK (LEFT SIDE OF DASH)
DATA LINK CONNECTOR (PARTIAL) (LEFT SIDE OF STEERING COLUMN)