


## FUSES & CIRCUIT BREAKERS

### FUSES & CIRCUIT BREAKERS

#### FUSE PANEL & FUSE BLOCK LOCATIONS

The vehicle has a fuse block with fusible links and a fuse panel with circuit fuses. The fuse panel is located in the L/H side of the instrument panel behind the instrument panel finish panel. The fuse block is located under the hood.

#### INTERIOR FUSE PANEL IDENTIFICATION



**Fig. 1: Interior Fuse Panel Identification**  
Courtesy of FORD MOTOR CO.

#### Interior Fuse & Circuit Breaker Identification

1 - 10 Amp ENGINE

Blower Motor Relay, Anti-Lock Brake System Relay, ABS System,

Ignition Main Relay, Air Bag

**2 - 15 Amp METER**

Instrument Cluster Warning Indicators, Heated Rear Window

Relay, Central Processing Unit Module, Backup Lights,

Instrument Cluster, Turn Signal Lights

**3 - 20 Amp DEFOG**

Heated Rear Window

**4 - 20 Amp**

Spare Fuse

**5 - 15 Amp**

Spare Fuse

**6 - Blank**

**7 - 15 Amp F.FOG**

Fog Lights

**8 - Blank**

**9 - Blank**

**10 - 20 Amp WIPER**

Front Wiper/Washer System, A/C Switch, A/C Relay,

A/C Condenser Fan Relay

**11 - 15 Amp R. WIPER**

Rear Wiper/Washer, Blower Motor, Daytime Running Lights (DRL)

Relay, (Canada Only),

**12 - 30 Amp BLOWER (Circuit Breaker)**

Climate Control Blower Motor

**13 - 15 Amp HAZARD**

Hazard Warning Flashers

**14 - 15 Amp STOP**

Luggage Compartment Light, Horn, Stoplights, ABS Control

Module, Horn Relay

**15 - 15 Amp TAIL**

Illumination, Turn Signal, Parking, Front Side Marker,

License & Tail Lights

**16 - 15 Amp CIGAR**

Cigarette Lighter, Audio

**17 - Blank**

**18 - Blank**

**19 - 10 Amp ROOM**


CPU Module, Powertrain Control Module (PCM), Interior Lights,

Radio Chassis, Backup Lights

**UNDERHOOD FUSE PANEL IDENTIFICATION**

The "high-current fuse panel is located in the engine compartment next to the battery.

**WARNING: Always disconnect battery ground cable before servicing "high-current fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.**



**50G11508**

**Fig. 2: Underhood Fuse Panel Identification**

**Courtesy of FORD MOTOR CO.**

## **Underhood Fuse Identification**

### **1 - 30 Amp Cooling Fan**

Electric Cooling Fan, A/C Condenser Cooling Fan, A/C Magnetic Clutch

### **2 - 60 Amp ABS**

Anti-Lock Brake System

### **3 - 80 Amp Main**

Hydraulic Anti-Lock Actuator Assembly, Powertrain Control Module (PCM), Anti-Lock Brake (ABS) Control Module, ABS Relay, Ignition Coil, Ignition Main Relay, Blower Motor Relay, Central Processing Unit (CPU), Instrument Panel Warning Indicators, Horn, Audio System, Heated Rear Window Switch/Relay, Air Bag Diagnostic Monitor, Rear Wiper/Washer, DRL Control Rely (Canada), Interior & Exterior Lights

### **4 - 30 Amp EGI INJ**

Multi-Port Fuel Injection (MFI) System, Air Bag Diagnostic Module

### **5 - 30 Amp Head**

Headlamps